


F5/TREMOLUX(mkII)



LEVEL - controls the intensity of modulation

RANGE - selects a tempo multiplier which is used to determine the final LFO frequency. Tap multipliers: x0.5, x1, x1.5, x2, x3, x4

SHAPE - selects between 8 waveforms:



SPEED - adjusts the frequency of the LFO

INTERNAL VOLUME TRIM - sets the output volume (=no more volume drops)

POWER SUPPLY (not included) 9VDC/100mA center negative